
ide Length	1				US	EU
21.9 cm					3y	35
21.1 cm					2.5y	34
20.3 cm					1.5y	33
19.5 cm					13.5 13	31 31
18.7 cm					12.5	
					11.5	29
17.9 cm			Shirt E.A.		11 10.5	29
17.1 cm		US	EU		10	27
16.3 cm		9	25		9.5	25
15.5 cm		8	24		8.5	24
14.7 cm	Months	7	23			
13.9 cm	18-24	6	22			
13.1 cm	12–18	5	21			
12.3 cm	9–12	4	20			
11.5 cm	6-9	3	19			
10.7 cm	0-6			7		



smaller by see kai run

Crib Shoes

Available in 5 sizes for kids 0-24 months

Add for Wiggle Room

Allow an extra 1/2 to one centimeter when selecting a size, more if the child will wear socks with the shoes.

see kai run

First Walkers

Available in whole sizes 3–9, for kids ages 6 months to 3 years

Round Up

If your child's foot falls in between sizes, round up. The extra room won't be there for long.

каі

Big Kid Shoes

Available in whole and half sizes 8–3y, for kids ages 2–8 years

Measure Often

Children's feet grow quickly. Measure at least every 2 months during the first year, and every 3 months from 1–8 years old.